

F3031S/F4031S VHF/UHF Handheld Transceiver

Chargers

| | |
|--------|---|
| BC160 | Desktop Rapid Charger |
| BC171 | Desktop Regular Charger |
| BC119N | Desktop Rapid Charger |
| BC197 | Multi Charger (includes AC adapter and charging cups) |
| BC121 | Multi-unit Gang Charger |
| BC157 | AC Adapter for BC121N |
| AD106 | Adapter Cup for BC119N or BC121N |

Batteries

| | |
|---------|---------------------------|
| BP232WP | 2000 mAh Li-ion 7.4V |
| BP240 | AAA Alkaline Battery Pack |
| BP261 | AA Alkaline Battery Pack |

Power Cables

| | |
|---------|--|
| CP23L | Cigarette Lighter Adapter for use with BC160 or BC119N |
| OPC515L | Power Cable for use with BC160 or BC119N |
| OPC656 | Power Cable for use with BC121N |

Speaker Microphones

| | |
|----------|-------------------------------|
| HM153LA | Earphone Microphone |
| HM158LA | Compact Microphone |
| HM159LA | Heavy Duty Speaker Microphone |
| HM166LA | Lapel Microphone |
| HM168LWP | Waterproof Speaker Mic |
| SP13 | Earphone |

Earphones

| | |
|------|---------------|
| SP27 | Tube Earphone |
| SP13 | Earphone |

Belt Clips and Hangars

| | |
|-------|-------------------------|
| MB93 | Swivel Belt Clip |
| MB94 | Aligator Type Belt Clip |
| MB96N | Swivel Type Hangar |
| MB96F | Fixed Type Belt Hangar |

Stubby Antennas

| | |
|----------|--------------------|
| FASC56VS | 150–162 MHz Stubby |
| FASC57VS | 160–174 MHz Stubby |
| FASC73US | 450–490 MHz Stubby |

Cut Antennas

| | |
|----------|-------------|
| FASC61VC | 136–174 MHz |
| FASC61UC | 380–520 MHz |

Flexible Antennas

| | |
|---------|-------------|
| FASC25V | 136–150 MHz |
| FASC55V | 150–174 MHz |
| FASC25U | 400–430 MHz |
| FASC57U | 430–470 MHz |

FASC72U 470–520 MHz

High Gain Antennas

FASC62V 150–160 MHz

FASC63V 155–165 MHz

Internal Units

UT109R Non Rolling Type Voice Scrambler

UT110R Rolling Type Voice Scrambler

UT108R DTMF Decoder

UT124R Man Down Unit